

CONTENTS

FLYSHEET	Guy lines attached
GROUNDSHEET	Living area
POLE BAG	2 Steel poles (3 sections for each pole) and 2 canopy poles
PEG BAG	Steel pegs
REPAIR KIT	Fabric patches, seam sealant, spare toggle and shock cords

Height 220cm



ERECTION INSTRUCTIONS

- 1: Remove contents from valise and identify each item.
- 2: Assemble poles, these come in three sections per 1 pole, 2 straight sides and 1 arch over the top. Where these poles fit together, they are in the shape of a trapezium where 1 side is longer than the other 3. Make sure you fit these sections together the correct way.
- 3: Lay flysheet on ground and form the shape of the tent.
- 4: Thread poles through pole sleeves then fit poles onto pins of the ring and pin system attached to the base of the flysheet.
- 5: Attach external black clips to the poles to erect tent.
- 6: Peg out placing pegs through the ring at the end of the four corners of the flysheet.
- 7: Guy lines are fitted and if used correctly will provide increased stability in adverse conditions, we therefore advise that the tent be guyed down as well as pegged. Always follow the line of the pole that the guy rope is attached to and peg into the ground in that line.
- 8: A living area groundsheet is provided and can be pegged in place using the eyelets.
- 9: After use ensure tents are clean and dry before packing away. Brushing or gently washing with luke warm water will remove any dirt or stains. Never use detergents as these can affect the waterproofing of the tent. Store in a cool dry place.

CONDENSATION

This is caused by moisture in the atmosphere, respiration and perspiration by the occupants. The moisture in the air comes into contact with the colder fabric and framework and condenses into water droplets. This is not to be confused with the tent leaking. On the contrary the problem is caused by water trying to get out of the tent rather than trying to leak in! Taking the following precautions can reduce condensation.

- 1: Adequate Ventilation
- 2: Do not cook inside the tent
- 3: Where possible avoid storing wet/damp clothing or equipment inside the tent.
- 4: Always take the opportunity to air sleeping bags when the sun is out, as sleeping bags tend to store moisture from the user.

FIRE RETARDANT

This Aztec tent is fire retardant proofed but, does not mean it is safe to cook or use naked flames within your tent.



DINING TENT