

## CONTENTS

FLYSHEET	Guy lines attached
INNER TENT	1 complete inner
GROUNDSHEET	For entrance areas (pre attached to inner)
POLE BAG	3 Fibreglass poles
PEG BAG	Steel pegs
REPAIR KIT	Pole repair sleeve, fabric patches, seam sealant, spare toggle and shock cord

Height 135cm

Inner Height 125cm



## ERECT FLYSHEET FIRST

- 1: Remove contents from valise and identify each item.
- 2: Assemble poles.
- 3: Lay inner on the ground. Thread the two longest poles carefully through the inner tent sleeves and peg out in each corner of inner. Place flysheet over the inner tent, tie the flysheet onto the inner tent poles with the tapes attached to the flysheet.
- 4: Thread short pole carefully through sleeve on the flysheet, fit the pole onto the pins at the front of the inner tent. Peg out using the elasticated loops. Ensure door zips are closed before pegging out.
- 5: The living area groundsheet is attached to the inner and should be hooked in place using the triangle buckles on the flysheet in the corresponding places.
- 6: Guy lines are fitted and if used correctly will provide increased stability in adverse conditions, we therefore advise that the tent be guyed down as well as pegged. Always follow the line of the pole that the guy rope is attached to and peg into the ground in that line
- 7: After use ensure tents (inner and outer) are clean and dry before packing away. Brushing or gently washing with luke warm water will remove any dirt or stains. Never use detergents as these can affect the waterproofing of the tent. Store in a cool dry place.

## FIBREGLASS POLES

If fibreglass poles are overtensioned they **will** split. A spare metal tube for an emergency repair is supplied in the repair kit.

## CONDENSATION

This is caused by moisture in the atmosphere, respiration and perspiration by the occupants. The moisture in the air comes into contact with the colder fabric and framework and condenses into water droplets. This is not to be confused with the tent leaking. On the contrary the problem is caused by water trying to get out of the tent rather than trying to leak in! Taking the following precautions can reduce condensation.

- 1: Adequate Ventilation
- 2: Do not cook inside the tent
- 3: Where possible avoid storing wet/damp clothing or equipment inside the tent.
- 4: Always take the opportunity to air sleeping bags when the sun is out, as sleeping bags tend to store moisture from the user.



# CASCADA 2